

APPLIANCE USAGE CHART

Could vary from min. kWh to max. kWh depending on family size and appliance.

To calculate cost, just multiply the kWh's by the Distribution Charge and by the Energy kWh Charge and add them together.

APPLIANCE	MONTHLY MIN. kWh	MONTHLY MAX. kWh	APPLIANCE	MONTHLY MIN. kWh	MONTHLY MAX. kWh
Clothes Dryer Electric	30	140	A/C Fan Continuous	260	
Clothes Washer (with w.h.)	35	200	A/C Fan Intermittent	50	150
Clothes Washer (other w.h.)	5	20	Humidifier (portable)	10	60
Computer	5	35	Lighting	20	150
Dehumidifier	40	260	Microwave	5	30
Dishwasher (with w.h.)	20	120	Range Electric	125	625
Dishwasher (other w.h.)	5	20	Refrigerator Frost Free	75	150
Electric Heater (1000 watts)	30	90	Television	5	40
Freezer	60	140	Water Bed Heater	60	120